

1970-72 Pontiac GTO AC Vent Instructions

#4107000

1. Carefully remove the AC vent from your original dash panel.
2. Insert it between tabs located on either side of the AC vent opening.



3. Locate the two retaining tabs and carefully insert them in order to retain the AC vent.



4. Apply a small amount of super glue or ABS glue to the back side of the tabs. Remember not to apply too much glue as it may telegraph and glue your vent solidly in place.

